

Customer Installed 120/240V Temporary Service

Notes:

1. Customer shall furnish and install a meter socket, service mast, weatherhead, raintight service box, ground consisting of a #6 (min) bare copper lead, and service hook capable of supporting 900# stress.
2. Wire out of weatherhead shall not be less than 3 feet.
3. Bare ground wire must connect at service panel & meter socket

